






























































































































































































































































































































































































































































































Движение вперед

Sequence of three blocks:

- Yellow block with a green play button icon.
- Green block with a motor icon and a blue tab labeled "8".
- Green block with a motor icon and a circular arrow icon.

Green block with a motor icon and a blue tab labeled "0".

Yellow block with a sand timer icon and an orange tab with a motor icon and an arrow icon.

Green block with a motor icon and a blue tab with a die icon.

Red block with a musical note icon and a blue tab labeled "1".

Red block with a screen icon and a blue tab with a die icon.

Bottom toolbar containing icons for:

- Motor with a fan
- Motor with a sand timer
- Motor with an 'X' (stop)
- Motor with a circular arrow (repeat)
- Motor with a circular arrow (repeat)
- Motor with a color wheel
- Red block with a musical note
- Red block with a screen
- Red block with a screen showing "123"
- Red block with a screen showing a plus sign

Right sidebar containing:

- A motor icon with a plus sign.
- A microphone icon.
- A green bar chart icon.
- A page number "4" at the bottom.